

THE FOLLOWING PAGE CONTAINS THE CONNECTION DETAILS

It is your responsibility to ensure that the transducer identification matches the connection details, including any RDP modification (T.M) references.

Please ensure that the transducer has not been modified or fitted with a cable or extension.

Particularly on DC-DC powered transducers, incorrect connection may cause **IRREPERABLE DAMAGE** to the transducer which is **NOT COVERED BY WARRANTY**


IF YOU ARE IN ANY DOUBT PLEASE CONTACT US



ACW SERIES (LVDT - OPTIONS 2,3,4,5,8,10,11)



CONNECTION DETAILS



ENERGISING SUPPLY : 0.5 to 7V r.m.s. 5kHz optimum.
SENSITIVITY : Refer to RDP Calibration Certificate.
CALIBRATED : 5V 5kHz energisation into 100k Ohms.
PHASING : YELLOW and GREEN are in phase with the armature fully extended.

RDP U.K.
Tel 01902 457512
Fax 01902 452000



Certificate No. FM 13141
BS EN ISO 9001:2008

**MADE IN THE
UNITED KINGDOM**

Doc. Ref. WDUK1401
ISSUE 6 - 22 SEP 2014

RDP U.S.A.
Tel 610 469 0850
Fax 610 469 0852